

LASTİK BASINÇ ÖLÇER



White LED lighted tip helps you find the tire stem easily

More easier use than conventional air gauges

Yellow pushbutton turns on/ off and units selected

Measures tire pressures of 5 to 100 pounds per square inch (PSI)

Press yellow pushbutton turns on, LCD display 0.0 PSI

Take the tire gauge spiracle at the tire stem, then the Tire gauge will memorize the maximal pressure valu

Press yellow pushbutton to select the different units, takes turns as
PSI Kpa Bar

Press yellow pushbutton 5s to turn off the tire gauge